

2-Pinion Style LCR Example is Landcruiser 40, 60, 75 Series



Remove cross shaft retaining bolt



Check spacer to cross shaft clearance is 6-20"



Slide Pins into mating half



Check intercam spacing 145-165"



Remove gears & thrust washers



Fit spacers into cam gears and grease teeth



Push spring behind pins



Slide cross shaft in